


utiliTEA

fast variable temperature kettle





adagio.com


© adagio teas, inc.



DIRECTIONS

HEAT WATER QUICKLY TO ANY TEMPERATURE

Press the button on handle to open the lid and fill the kettle with water. Please adhere to the "min" and "max" markers. Settle the kettle on base and plug into outlet. To boil water, press the **on/off**  button. To choose a variable temperature, press the **+/-** **button** until your choice is illuminated. Press the **on/off**  button briefly to heat water to your desired temperate. The green temperature light will glow solid and kettle shut off automatically at your selected temperature. To heat water and keep it warm for 30 minutes, press the on/off button until the temperature light pulses.



Please use the reference guide on the back for the recommended temperature settings for all tea varieties.

CLEANING

Unplug the power cord and permit kettle to cool before cleaning it. Wipe outside with a soft damp cloth. Rinse inside with clean water. After extensive use, scale may build up inside. To remove, fill the kettle with vinegar and let soak overnight. Dispose of vinegar in the morning, fill with water and bring to boil. Pour water out and rinse thoroughly.



WARNING

Children are often unaware of the danger posed by electrical appliances. To protect children, please keep this kettle and other appliances out of their reach. For indoor use only. To prevent fire, electrical shock or personal injury, please, observe these precautions:

- Do not heat any liquid other than water.
- Do not immerse power cord, plug or base unit in water
- Do not operate if electrical components are wet.
- Do not operate with damaged power cord or plug.
- Do not disassemble the kettle or base unit.